

Hygomat – Antibacterial Floor Mat

INSTRUCTIONS

Never place on wet or dirty floor

1. Thoroughly clean floor and allow it to dry completely
2. Remove protective strip from adhesive under the mat
3. Place with adhesive furthest from the urinal
4. Activate time strip at placement by pressing the round blister briefly but firmly until you hear a light pop. Red liquid will slowly fill the time strip indicating the time in use, 1 to 4 weeks.
5. Chose a schedule for replacement:

<u>Heavy Traffic</u>	<u>Medium Traffic</u>	<u>Light Traffic</u>
400+ uses / day	200+ uses / day	Under 200 uses / day
<i>Replacement Schedule:</i>		
Weekly	All 2 - 4 weeks	All 4 weeks

- Important:**
- Clean floor around the mat, not under the mat until it is replaced
 - Hygomats are a one-way-product, not to be reused

CHARACTERISTICS

Anti-Bacterial Effect

- Effectively inhibits the build-up of bad odor caused by bacterial breakdown of urine, e.g. into ammonia.
- Prevents bacteria from spreading through the air by evaporation.

Protects Floor from Staining

- The floor underneath urinals needs special protection from extremely aggressive urinal acids; even a tile floor can be ruined within hours.

Increases Safety

- Through the adhesive, the slip and fall risk is greatly reduced.
- Urine is safely concealed and absorbed, it will not puddle or cause slippery surfaces.

Simplifies Washroom Maintenance

- Reduces maintenance costs and keeps floors, only mopping around the mat is necessary.
- Even if moist from mopping water (but not soaked for a longer period) the anti-bacterial effect stays effective.